Rev.01/2013

USER'S MANUAL

UNIVERSAL AIR CONDITIONER REMOTE CONTROL

COD. 11132199

Toolsplit®

Strumenti & Utensili

by Tecnosystemi® group

INTRODUCTION

1. ON/OFF key: press it once to turn the air conditioner on or off
2. Temperature increase: press it once, temperature increases 1°C
3. Temperature decrease: press it once, temperature decreases 1°C
4. Mode switch: press the key, work mode is changed as per the following sequences: AUTO-COLD-DRY-VENTILATION- HEAT
5. Air flow speed
6. Automatic air flow direction: press the key to change air flow direction between automatic and manual
7. Manual air flow direction: press the key to change air flow direction
8. Press it to confirm selected model code
9. Auto search code
10. Code selection +
11. Code selection -
12. Reset function
13. Press to run the search



Model Code Table

CARRIER	163-164-165-166-167	HUALING	195-196-197	PHILCO	146-147
CHANGONG	200-201-202-203-204-205	HUIFENG	120	SAMSUNG	106-107-108-109-
CHIGAO	207-208	HUIKANG	96	SANYO NEC	035-036-037-038-039 040-041-042-043-044 045-046-047-048-049 050-051-052-053-054 055-056-057-058-059
CHOFU	121-122-123-124	JDC	191	SAIJO DENKI	0176-0177-0178-0179-0180
CONROWA	198	JOHSON	135	SHANGLING	199
CORONA	097-098-099-100-101-102-103	KANGLI	144-145	SHARP	068-069-070-071-072 073-074-075
DAIKIN	110-111-112-113-114-115	KELON	157-158	SHENGFENG SHANNGLU	154
DOCTOR	162	KLIMATAIR	155-156	SHUANGLU	206
ELECTRA	174-175	KONKA	188	SOVA	186-187
ELECTROLUX	148-149-150	LG	116-117-118-119	TCL	125-126-127
FUJITSU	088-089-090-091-092-093-094-095	MACQUAY	128-129-130-131-132-133-134	TOSHIBA	076-077-078-079-080 081-082
GALANZ	142-143	MIDEA	189-190	TRANE	168-169-170
GOLDSTAR	136	MITSUBISCHI ELECTRIC	025-026-027-028-029-030-031-032-033-034	UNI-AIR	159-160
GREE	172-173	MITSUBISCHI INDUSTRY	001-002-003-004-005-006-007-008-009-010-011-012-013-014-015-016-017-018-019-020-021-022-023-024	WEILI	171
GUQIAO	161	NATIONAL PANASONIC	060-061-062-063-064-065-066-067	WHIRLPOOL	137-138-139-140-141
HAIER	191-192-193-194-			YORK	182-183-184-185
HITACHI	083-084-085-086-087				
HISENSE	104-105				
HUBAO	151-152-153				

Model Setting of Remote Control

1. Pull away the upper lead of the remote control in order to release it laterally, insert 2 batteries type AAA according to its correct polarity on the batteries compartment.

2. Look for the model code from the model code list, if there are more models for the same brand, select the one most suitable to your conditioner. E.g.: SANYO, try to set up codes from 035 to 039.

3. Press the reset key (12) with a sharp object, preferably a pencil, the code will flash on the display. Press the ‚+' or ‚–' key until the selected model code will appear. Then press the ‚ENTER' key (8) to confirm the selection and the code will Stop flashing. Point the remote control toward the conditioner by pressing the 'ON/OFF' key (1) and verify the correct functioning of the remote control.

Remote Control Auto Search

If you don't know the model of the conditioner or if the model is not listed on the code list then proceed as follows:

1. With a pencil press the ‚SET' key (13), the code will flash on the display. Always keep the remote control pointed toward the conditioner. Press the AUTO search key (9) and the first code will appear on the display, keep on pressing and release it (the following codes will appear) until the conditioner will produce a confirmation sound. Press the ‚ENTER' key (8) to confirm.

2. Then verify the functions of all the keys, if these do not respond correctly then repeat the auto search procedure once again.

WARNING

1. Remove the batteries from the remote control if you don't use it for a long time. If the display looks dim, substitute the batteries (do not use exhausted batteries together with new ones). When removing the batteries, after a few seconds, the remote control will loose the code memory so it will be necessary to reset it again.

2. If the remote control does not work properly, remove the batteries for a few minutes, then repeat the procedure.

3. This remote control may not be working with some conditioner models, this is not due to the malfunctioning of the remote control, but this may be due to some technical settings made on the conditioner by the manufacturers.

Technical Parameters

Controllable distance :	Large than 8 meters
Power supply voltage:	DC 3 V
Battery model:	Battery AAA(UM-4、R03)×2
Dimension:	L160mm×W58mm×D18mm
Weight:	Approx.95g(excl.the batteries)